Performance Structural Concrete Solutions, LLC P.O. Box 2377, Davidson, NC 28036-2377 P: 980-333-6414 info@pscs-llc.com • www.pscs-llc.com



Installation Guidelines: Straight HC-Omega & Corrugated HC-Omega on Insulation

Training:

Upon request PSCS provides training services. Our team can assist your crew in the installation of the armored free movement joints providing recommendations for the layout, detailing, and best practices. If your project needs specialized attention, our associates can provide recommendations on a case by case basis.



Figure 1. HC-Omega[®] as installed on insulation.



Figure 2. HC-Omega Sinus Slide[®] as installed on insulation between door posts.

Instructions:

- 1. String a line or snap a line using Chalk String where the profiles are to be installed.
- 2. Lay the joints out along this line.
- 3. Place the first joint parallel to this line.
- 4. Bring them to the correct height using wedges or the height adjustment tool.
- 5. Screw "L" brackets to the insulation on both sides of the joint and both ends of the joint.
- 6. Place another set of "L" brackets at the middle of the joint. See Figure 3.
- 7. Check the height level of the profile with a laser and check the alignment relative to the taut line or the snap chalk line.
- 8. Use a level to check the levelness of the profile across the length.
- 9. Weld the "L" brackets to the top flange of the joint. If welding work is not permitted on site, special adjustment feet are available.
- 10. Place the next profile with its overlap in the first profile. With the second profile matching the first profile, the start of the second profile is immediately at the correct height.

Installation Guidelines: HC-Omega[®] and Sinus Slide[®] on Insulation



- 11. Bring the end of the second profile to the correct height with wedges or the height adjustment tool.
- 12. Weld the two joint sections together on the side of the top flange and the bottom flange.
- 13. Repeat these steps 5 to 12 until an intersection, wall or column is reached.
- 14. If the slab reinforcing is rebar or wire mesh, be careful not to weld the slab reinforcing steel or wire mesh to the armor joint. The joint must expand and contract with the concrete not the steel. If the joint is welded to the reinforcing steel, the slab will not perform optimally.



Figure 3. Placing HC-Omega[®] on insulation with "L" brackets before installing rebar reinforcing.



Figure 4. HC-Omega[®] as installed on insulation with adjustable feet.

For intersections:

- 1. Place the intersection in the location specified on the layout plan.
- 2. Measure the distance between the last placed joint and the intersection. Cut the joint to be placed to the correct length using a quickie saw.
- 3. Place the joint that has been cut to length according to the procedure described above.
- 4. Bring the intersection to the correct level and weld it to the joint. Remember to weld the supplied noses on to prevent the penetration of poured concrete into the joint.

Tools & Supplies:

- 1. Welding team.
- 2. Portable self-contained welding machine such as the "Blue Star® 185" by Miller or equivalent.
- 3. Quickie saw for cutting the joints as needed.
- 4. Crossings for intersections or qualified trainers to assist with the installation.
- 5. "L" brackets or adjustable feet for stability on insulation, at least every 5 feet.
- 6. Screws for screwing down "L" brackets.
- 7. Cordless drill.
- 8. Height adjustment and levelling: Adjustable feet, wood wedges, or The Height Adjustment and Levelling Tool.
- 9. String for making a straight guide line.

Disclaimer: All of these guidelines are for general information only. Please contact our representatives for further inquiries.